


# AIR LINK DW 20BR

## Controls



- 1 **PAIR** button – enables the unit to become available for pairing by pressing and holding the button for 3 seconds. The LED ring will indicate the current status. See the Getting Started section for details.
- 2 **LEVEL** knob – adjusts the volume of the signal sent to the output jacks.
- 3 **DC INPUT** – accepts the included power adapter.
- 4 **OUTPUTS** – connect to an amp, powered speakers, or mixer via balanced XLR or unbalanced 1/4" TS cables.

## Getting Started

1. Connect the DW 20BR to a mixer or speaker system with either XLR or 1/4" cables. Keep the volume on the speaker or mixer channel turned all the way down to avoid popping noises.
2. Connect the power adapter to the DW 20BR and to a power outlet. The unit will turn on automatically.

3. Activate Bluetooth connectivity on your Bluetooth device. The DW 20BR will automatically try pair with the most recently connected device, in which case you can start playing audio right away.
4. To connect a new device, press and hold the PAIR button for 3 seconds. The LED ring will flash quickly to indicate that it is ready to pair.
5. Select the DW 20BR from the list of available items in the Bluetooth settings menu of your Bluetooth device.

**Note** - disable cellular reception when streaming audio from a cell phone.

6. Start playing audio from your Bluetooth device. Adjust the volume on the Bluetooth device, then turn up the LEVEL knob so that the speaker or mixer receives a strong signal.
7. Turn up the volume on your speaker, mixer, amps, etc. until you reach the desired listening level.

**Note** - If your Bluetooth audio device is compatible, Play/Pause can be toggled with a short press of the PAIR button on the DW 20BR while the bluetooth stream is active.