

# The Basic

## What's Included



Speaker



Microphone




Audio Cable



XLR Cable



IEC Cable




Stands

## Speaker Set-Up Instructions




Keep this set to 'OFF'.


This knob is where you adjust the volume.



This is where you plug in the IEC Cable.



This is where you plug in the Microphone with an XLR cable.



This is also where you plug in the Audio Cable.

**PLEASE NOTE:** You can't have the Microphone and Audio Cable plugged in at the same time with this Basic Package.

## Questions?

- Visit our website at [www.speakeronastick.com](http://www.speakeronastick.com). Click on the 'How To' page and review our 'Troubleshooting' section.
- Reach us at (727) 444-0290 if you rented from our Clearwater, FL location or (616) 988-9671 if you rented from our Grand Rapids, MI location. If your call is outside our business hours, you **must** leave a voicemail for us to be notified that you've called. We will receive the notification on our cell phones. Once we're notified, we'll return your call as soon as possible.
- Send us an email at [info@speakeronastick.com](mailto:info@speakeronastick.com).