

# MACKIE 1402 MIXER



## BACK OF MIXER:



This is where you plug in the Power Cable.



This is where you plug in the speakers or sub using XLR cables.

## TOP OF MIXER:



This is where you plug in the mic using an XLR cable.

Make sure all the knobs in this row are set to 'U' or 12 o'clock, pointing straight up.



This is where you plug the iPod cable into its respective colors.

Make sure these buttons are pushed DOWN.

Microphone Volume\*\*

Master Volume  
(Both Faders - keep at same level)

Music Volume\*

\*\* Adjust the Microphone Volume FIRST by talking into the microphone and moving the fader up until you reach the desired volume level.

\* Adjust the Music Volume AFTER your microphone volume has been set. Do so by playing music & moving the fader up until you reach the desired volume level.