

# MACKIE 402 MIXER



## BACK OF MIXER:



This is where you plug in the Mackie Power Cable.



## ADDITIONAL ITEMS:



Adapter Cables



Mackie Power Cable

## TOP OF MIXER:



This is where you plug in the microphone using an XLR cable.



This is where you plug in the sub or speakers using the adapter cables and XLR cables.



This is where you plug the iPod cable into its respective colors.

Make sure these knobs are set to 'U', or 12 o'clock.

Music Volume\*

Microphone Volume\*\*

\*\*Adjust the Microphone Volume FIRST by talking into the microphone and turning the knob until you reach the desired volume level.

\*Adjust the Music Volume AFTER your microphone volume has been set. Do so by playing music and turning the knob until you reach the desired volume level.