

The Basic




What's Included













Microphone

Audio Cable


IEC Cable

Stands


Speaker Set-Up Instructions



These knobs are where you adjust the



This is where you Microphone with an XLR cable.



Cable.

THRU



This is where you plug in the Audio Cable.

Questions?

- Visit our website at www.speakeronastick.com. Click on the 'How To' page and review our 'Troubleshooting' section.
- Reach us at (727) 444-0290 if you rented from our Clearwater, FL location or (616) 988-9671 if you rented from our Grand Rapids, MI location. If your call is outside our business hours, you must leave a voicemail for us to be notified that you've called. We will receive the notification on our cell phones. Once we're notified, we'll return your call as soon as possible.
- Send us an email at info@speakeronastick.com.