The BT DJ



What's Included

















Speakers

Subwoofer

Microphone

Mixer

Audio Cable (for backup)


XLR Cables

bles IEC Cables

ables Stands

Subwoofer Set-Up Instructions





IEC Cable.

This is where you plug into the LEFT speaker using an XLR Cable.





& this is where you plug into the RIGHT speaker using an XLR Cable.



Keep this knob set to 'U', or straight up.







Use this wheel to scroll and click through options on the LCD screen.*

This is where you plug in from the Sub.

Plug from 'L MAIN OUT' on the mixer into the LEFT speaker using an XLR Cable.





Plug from 'R MAIN OUT' on the mixer into the RIGHT speaker using an XLR Cable.

* Reference the supplemental Thump 12BST Bluetooth Owner's Manual sheet for instructions on how to link the speakers together, and how to pair your device to the Primary speaker via Bluetooth.

Questions?

- Visit our website at www.speakeronastick.com. Click on the 'How To' page and review our 'Troubleshooting' section.
- Reach us at (727) 444-0290 if you rented from our Clearwater, FL location or (616) 988-9671 if you rented from our Grand Rapids, MI location. If your call is outside our business hours, you must leave a voicemail for us to be notified that you've called. We will receive the notification on our cell phones. Once we're notified, we'll return your call as soon as possible.
- Send us an email at info@speakeronastick.com.